



Please read this manual carefully before operating your set and retain it for future reference.

To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL



www.lg.com

Copyright © 2018 LG Electronics Inc. All Rights Reserved. 1806_Rev02

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20 cm (7.8 inches) between the antenna and your body. Users must follow the specific operating instructions for satisfying RF exposure compliance.

FCC Radio Frequency Interference Requirements:

High power radars are allocated as primary users of the 5.25 to 5.35 GHz and 5.65 to 5.85 GHz bands. These radar stations can cause interference with and/or damage this device. This device cannot be co-located with any other transmitter.

Responsible Party:

LG Electronics USA, Inc. 1000 Sylvan Avenue Englewood Cliffs, NJ 07632 Tel: 1-800-243-0000





1-800-243-0000 1-888-865-3026 USA, Consumer USA, Commercial

Register your product Online!

www.lg.com

Printed in China

SK4D.DUSALIK_SIM (Sheet)_MFL70585603.indd 1,4



Front Panel

The buttons are located on the rear.




ال Standby / On

F Selects Function



Rear Panel



DC IN Connect to the AC adapter
OPTICAL IN Connect to an Optical device
USB ← Connect to a USB device

1 Subwoofer Connection

Place the wireless subwoofer near the sound bar and follow steps below.


- Connect the power cord of the sound bar and the wireless subwoofer to the outlet.
- 2 Turn on the sound bar.
- 3 The sound bar and wireless subwoofer will be automatically connected. The subwoofer's yellow green LED turns on.

Manually Subwoofer Connection

If the subwoofer does not make sound, try to connect manually.


- Press PAIRING button on the rear of the wireless subwoofer.
- The yellow green LED on the front of the wireless subwoofer blinks quickly. (If the yellow green LED does not blink, press and hold the **PAIRING** button.)
- 2 Turn on the sound bar.
- 3 Pairing is completed.
- The yellow green LED on the front of the wireless subwoofer turns on.

Keep the sound bar and the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1 m (3.3 ft) to prevent wireless interference.




TV Connection

- Connect the sound bar to the TV using Optical
 cable.
- 2 Set up [External Speaker (Optical)] on your TV setting menu.



Additional Device Connection

Connect to the external device as follows.



2 Set the input source by pressing **F** repeatedly.

Remote control




ASC/BASS BLAST/CINEMA: Selects the sound effect.

NIGHT ON/OFF: Turns down the volume at night.

WOOFER LEVEL +/-: Adjusts the volume level of subwoofer.

AUTO POWER ON/OFF: Automatically turns on by an input source.

Replacement of battery



Additional Information

Specification

Refer to the main label.
Model: DA-38A25 Manufacturer: Asian Power Devices Inc. Input: 100 - 240 V - 50 - 60 Hz Output: 25 V 1.52 A
Approx. 890.0 mm x 53.0 mm x 85.0 mm (35.0 inch x 2.1 inch x 3.3 inch) Without foot
5 V === 500 mA
300 W RMS

Design and specifications are subject to change without notice.



2018-07-03 8:20:44 SIM (Sheet)_MFL70585603.indd 5-8